



| ITEM NO. | PART NO. | DESCRIPTION | QTY. REQ'D |
|----------|----------|--------------------------------------|------------|
| 1 | S01628 | Field Assembly | 1 |
| 2 | 01160 | Field Mounting Screw | 2 |
| 3 | 01059 | Field Screw Lockwasher | 2 |
| 4 | 03998 | Swivel Stud Screw | 1 |
| 5 | 01077 | Armature Link | 1 |
| 6 | 01070 | Top Swivel Stud Washer | 2 |
| 7 | 01296 | Internal Lockwasher | 1 |
| 8 | 17069 | Mounting Plate Screw | 1 |
| 9 | 06009 | Ground Screw (used with 3-wire cord) | 1 |
| 10 | 01583 | Cord Retaining Clip | 1 |
| 11 | 01643 | 2-Wire Cord (ML Clipper) | 1 |
| 12 | 01648 | 3-Wire Cord (ML-CSA/GC-UL/CSA) | 1 |
| 13 | 01767 | Switch Assembly | 1 |
| 14 | 01699 | Cover Screw | 2 |
| 15 | | Cover | 1 |
| 15a | 01629 | Cover (ML-UL) | 1 |
| 15b | 01288 | Cover (ML-CSA) | 1 |
| 15c | 02007 | Cover (GC-UL) | 1 |
| 15d | 01738 | Cover (ML-Fade Master) | 1 |
| 15e | 02103 | Cover (ML-Experience) | 1 |
| 15f | 02431 | Cover (ML-Phat Master) | 1 |
| 16 | 01639 | Switch insulation | 1 |
| 17 | 60003 | Actuating Arm | 1 |
| 18 | 02048 | Adjusting Screw | 1 |
| 19 | 01716 | Stabilizer Screw | 1 |

| ITEM NO. | PART NO. | DESCRIPTION | QTY. REQ'D |
|----------|----------|--|------------|
| 20 | 02047 | Stabilizer Spring | 1 |
| 21 | 01616 | Hanger Bail | 1 |
| 22 | 60002 | Switch Button | 1 |
| 23 | 03001 | Adjusting Lever Tension Spring | 1 |
| 24 | 01626 | Adjusting Lever | 1 |
| 25 | 03005 | Ball Pin | 1 |
| 26 | 01581 | Blade Pad and Guide Assembly | 1 |
| 27 | 01053 | Lower Blade Screw | 2 |
| 28 | 17808 | Blade Pad Assembly Screw | 4 |
| 29 | 75296 | Blade Guard | 1 |
| 30 | S01641 | Armature Assembly (includes Connector Fork, Connector Fork Washer, Connector Fork Screw, Bottom Swivel Stud Washer, and Armature Adjusting Screw.) | 1 |
| 31 | 01400 | Connector Fork | 1 |
| 32 | 01213 | Connector Fork Washer | 1 |
| 33 | 03537 | Connector Fork Screw | 2 |
| 34 | 03021 | Bottom Swivel Stud Washer | 1 |
| 35 | 13079 | Armature Adjusting Screw | 1 |
| 36 | | ML Case Sub Assy | |
| | 200346 | ML Case Sub Assy | 1 |
| | 200347 | ML Case Sub Assy - Red | 1 |
| | 200348 | ML Case Sub Assy - Black | 1 |
| | 200349 | ML Case Sub Assy - Phat Master | 1 |

IMPORTANT INFORMATION

When ordering repair parts, include part number, part name and model of trimmer. For best performance, trimmer blades should be CLEANED and OILED with Andis Clipper Oil before and after use. If repair is necessary, return to any Andis Authorized Repair Service Station, or to Andis Company, 1800 Renaissance Blvd., Sturtevant, Wisconsin, 53177 U.S.A.. Pack carefully, mail either Insured Parcel Post, or U.P.S., attach a letter to outside of package explaining difficulty.